



ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. While threading wire through, assemble the rods (4) together using the nipples (3).
Attach the end of the rods (4) into the coupling (6) until hand tight.
4. Secure the loop (5) onto the other end of the rods (4).
5. Use quick link to connect the loop (5) to the loop on the canopy (1) and twist the locking mechanism to secure.
6. Install the G9 LED bulbs (7) into each socket (8).
7. Refer to the additional installation instructions included with the product for wiring and installation.
8. Restore power to the installation point and retain this sheet for future reference.